

## Software Mode Map Guide

**Firmware:** v5.0  
**Description:** "Stock Only" Software  
**Product:** LRP Flow Competition + Flow WorksTeam  
**Part No.:** 80960 + 80970

This optional firmware differentiates to the standard firmware/product manual in the areas highlighted pink:

MODE Level	1	2	3	4	5	6	7	
Red LED								
Blue LED								
Yellow LED								
Value Green LED	Auto Brake	Initial Drive	Torque Timing	Boost Timing	Boost		Boost Turbo	CutOff Voltage
	[%]	[%]	[°]	[°]	Trigger [kRPM]	Angle [°/10k]	[°]	[V]
0	0		0	0			0	disabled
1	3	5	5	23	5,1	8	5	3,2
2	6	7	10	26		10	7	4,0
3	9	9	15	29		12	10	6,4
4	12	12	20	32		14	12	
5	15	15	25	35		16	15	
6	20			38		18		
7	25			41		20		
8	30			44		25		
9	35			47		30		
10	40			50		35		